



Jeppesen® Unlock Wizard Operation Instructions

CONTENTS:

1. Introduction - *page 1*
2. Installation - *page 2*
3. Creating an Account - *page 2*
4. Unlocking A Jeppesen Aviation Database File - *page 3*
5. Unlocking Monthly Installments of an Annual Subscription - *page 4*

Introduction:

Locked/Unlocked Files

Jeppesen Sanderson, Inc. issues updated versions of the Jeppesen® Americas and Jeppesen® International aviation databases every 28 days. These files can be downloaded from the web site, www.lei-extras.com.

Jeppesen database files have two states, locked and unlocked. The locked state is used for copy protection. *Your GPS unit can read a database file only if the file has been unlocked AND assigned to a single MMC or SD card by the Jeppesen Unlock Wizard.* The Jeppesen database files downloaded from the LEI web site are always locked.

Locked or unlocked files are the same size; the files are not compressed or zipped. You can back up either a locked or unlocked database file on your hard drive, a CD or other removable media, such as a Zip® disk.

In your GPS unit, the database is stored only on the MMC or SD card. The GPS unit automatically reads aviation mapping data from the card. The aviation database is not stored in the GPS unit's onboard memory. When you remove the card from your unit, the aviation data goes with it!

Purchasing Options

Single:

A single purchase is a one-time unlock of a Jeppesen aviation database file.

Annual Subscription:

An annual subscription is a cost-effective way to keep your aviation database current. A subscription includes 13 unlocks, one for every 28 days. An unlock *must* be used during it's respective 28-day cycle or it will expire. Also, you can *only* use one unlock per 28-day cycle.

Why Internet Access is Needed

The Jeppesen Unlock Wizard is a powerful on-line tool for purchasing LEI Jeppesen updates, replacing traditional mail-order methods. The Jeppesen Unlock Wizard enables you to pay for a database update and unlock it to any card of your choice, 24 hours a day, seven days a week. In order for LEI to confirm your identity, approve your credit card and track your purchase, the Jeppesen Unlock Wizard must communicate directly with LEI. The Wizard does this by connecting to an LEI web server over a secure Internet connection.

Installation (From Web or CD)

Step 1. From Web: Open the wizard installation file you downloaded, JEPPSETUPNET.exe, and follow the on-screen instructions. **From CD:** Depending on which edition of MapCreate™ you purchased, the installation file may be available on the MapCreate install disc, in the root directory. (**NOTE:** some anti-virus software may cause installation errors. You may need to temporarily disable any anti-virus program before running the wizard installation.)

Step 2: The wizard will be installed in the default folder <C:\Program Files\LEI\JeppesenUnlockWizard>. The installation program will create a shortcut to the wizard in **START | PROGRAMS | LEI | JEPPESEN UNLOCK WIZARD**.

Step 3: After installation is complete, you can launch the wizard by clicking the **START** button and choosing **JEPPESEN UNLOCK WIZARD** from the menu or you can double-click the unlock wizard icon in the LEI program group.

Creating an Account

You must first create an account with LEI before you can unlock a Jeppesen database file. (If you have already created an account, a log-in dialog box will appear when you launch the Wizard. Enter your User Name and Password, then skip to "Unlocking a Jeppesen Aviation Database File" on page 3.)

Step 1: Log onto the Internet, and then launch the Jeppesen Unlock Wizard: click **START | PROGRAMS | LEI | JEPPESEN UNLOCK WIZARD**. Wait while the wizard initializes contact with the web server. The Wizard will show a splash screen while this process occurs.

NOTE:

Depending on your connection speed and the level of Internet traffic, this could take a few seconds or several minutes.

Step 2: If you are running the Wizard for the first time, a Welcome screen appears after the Wizard sets up its connection to the LEI web server. Click **OK** to create your account.

Step 3: Enter a User Name and a Password. You can use any combination of letters and numbers.

NOTE:

We recommend you either memorize or write down your user name and password at this point. Remember that both your user name and password are case sensitive.

Step 4: Enter your personal information. This information is only used by LEI to create and track your order. When all fields have been filled in, click on the **CREDIT CARD INFORMATION** tab.

Step 5: Enter your credit card information.

Step 6: Select the desired e-mail and password options at the bottom of the screen, then click **SAVE**. When your account is created, the Wizard will open the Select Aviation Database screen, where you begin the process of unlocking your file.

Unlocking a Jeppesen Aviation Database File

Assuming you have successfully downloaded a database file from the LEI Extras web site to your memory card, and are logged in to your new or existing online account, unlock your file by following these steps:

Step 1: Select your aviation database file location and purchasing option: Use the **BROWSE** button to find where you downloaded the file on your memory card. Select the file and click **OPEN**. Select the "Single" or "Annual" purchasing option, then click **NEXT**.

See "Unlocking Monthly Installments of an Annual Subscription" on page 4 for more on Annual subscriptions.

Step 2: Verify the memory card you want to use: Make sure you have the correct card in the reader and that the reader's drive letter is correct. If the information is correct, click **NEXT**. If this is not the card you intended, copy the file to the desired card, and proceed with that card in the reader.

Caution:

When the wizard is finished, the Jeppesen data will ONLY work on the card you have selected! You will NOT be able to use this data file on any other memory card without being charged again.

Step 3: Confirm your order: Make sure all your personal information is correct. If the information is correct, click **FINISH**. (Your credit card will be charged at this point and the wizard will automatically complete the remaining steps.) If an entry is wrong, click **BACK** until you see the appropriate screen(s). Make the correction, then click **NEXT** until you return to this screen, then click **FINISH**.

Steps 4 & 5: (Automatic) Process credit card and unlock aviation database: A status window will appear, showing the progress of these steps. Please be patient and do not interrupt your computer. Depending on your connection speed and the level of Internet traffic, this could take a few seconds or several minutes.

WARNING:

Do not attempt to close the wizard or remove your card during this step. Interrupting this process could result in your credit card being charged without the data being unlocked.

Step 6: Summary: This screen appears after the wizard has successfully completed steps 4 and 5. Click **CLOSE** to end the wizard. You can now log off the Internet. After you have backed up the file, it is safe to remove your card from the reader. Insert the card in your AirMap[®] GPS unit and you're ready to head for the airport.

WE STRONGLY RECOMMEND that you now back up the unlocked file.

Troubleshooting

If credit card authorization failed for some reason, you will be returned to the Account Manager screen. Please check your information or enter a different credit card number and try again. If continued attempts fail, please check the status of your card with your credit card company. If the credit card account is working correctly, please contact Customer Service for assistance at 1-800-324-4740, or e-mail: lei-extras@lowrance.com.

Unlocking Monthly Installments of an Annual Subscription

To *start a new* annual subscription follow the steps in "Unlocking A Jeppesen Aviation Database File" on page 3. Be sure to select the "Annual" option on step 1. If you have already started your subscription, proceed with the following steps:

Step 1: Download the latest Jeppesen database file from the LEI web site (www.lei-extras.com) to your memory card.

Step 2: With the memory card in the card reader, start the Unlock Wizard. If you didn't check the "Show At Startup" option when you selected your annual subscription (Step 3), click **NEXT** until you see the Select Aviation Database screen. (The wizard remembers your personal information.) If you did check "Show At Startup," the wizard opens with the Select Aviation Database screen.

Step 3: Select your aviation database file location: Use the **BROWSE** button to find where you downloaded the new file on your card. Select the file and click **OPEN**. Confirm that the Annual option is selected. The wizard will also show how many unlocks remain in your subscription. If the information is correct, click **NEXT**.

NOTE:

If the Annual option shows a dollar amount, see the Troubleshooting section on page 6.

Step 4: Verify the memory card you want to use: Make sure you have the correct card in the reader and that the reader's drive letter is correct. If the information is correct, click **NEXT**. If this is not the card you intended, copy the file to the desired card, and proceed with that card in the reader.

Step 5: Confirm your order: Make sure all your personal information is correct. The total charges should show zero dollars if you still have unlocks remaining on your subscription. If the information is correct, click **FINISH**, and the wizard will automatically complete the remaining steps. (If an entry is wrong, click **BACK** until you see the appropriate screen(s). Make the correction, then click **NEXT** until you return to this screen, then click **FINISH**.) A confirmation message appears, telling you what unlock you are performing and how many remain. Click **OK** to proceed.

Steps 6 & 7: (Automatic) Process credit card and unlock aviation database: A status window will appear, showing the progress of these steps. Please be patient and do not interrupt your computer. Depending on your connection speed and the level of Internet traffic, this could take a few seconds or several minutes. For your protection, your personal and credit card information is sent to LEI over a secure connection.

WARNING:

Do not attempt to close the wizard or remove your card during this step. Interrupting this process could result in failure of the data unlock procedure.

Step 8: Summary: This screen appears after the wizard has successfully completed steps 6 and 7. Click **CLOSE** to end the wizard. You can

now log off the Internet. After you have backed up the file, it is safe to remove your card from the reader. Insert the card in the AirMap and you're ready to head for the airport with your new database file.

WE STRONGLY RECOMMEND that you now back up the new unlocked file.

Tip:

By checking the reminder option in the wizard's Account Manager, you will be notified by e-mail when each 28-day update period begins.

NOTE:

A subscription allows 13 consecutive unlocks. Each individual unlock must be used in its respective cycle or it will expire. When your subscription ends, the wizard will remember your personal information and will reset itself, awaiting your next single or annual database purchase.

Troubleshooting

If the Annual option in Step 3 shows a dollar amount, continuing with the wizard will charge you for a new annual subscription. There are three possible causes for this. 1 – No annual subscription was started for the account. 2 – The subscription's remaining unlocks have been used (the subscription has expired). 3 – An error has occurred in the program. In the case of item 3, please call Customer Service.

LEI DATABASES LICENSE AGREEMENT

THIS IS A LEGAL AGREEMENT BETWEEN THE END-USER WHO FIRST PURCHASES THIS PRODUCT AS A CONSUMER ITEM FOR PERSONAL, FAMILY, OR HOUSEHOLD USE ("YOU") AND LEI EXTRAS, A DIVISION OF LOWRANCE ELECTRONICS, INC., THE MANUFACTURER OF THIS PRODUCT ("WE", "OUR", OR "US"). USING THE PRODUCT ACCOMPANIED BY THIS LICENSE AGREEMENT CONSTITUTES ACCEPTANCE OF THESE TERMS AND CONDITIONS. IF YOU DO NOT ACCEPT ALL TERMS AND CONDITIONS, PROMPTLY RETURN THE PRODUCT WITHIN 30 DAYS OF PURCHASE. PLEASE RETURN USING THE ENCLOSED UPS SHIPPING LABEL AND INCLUDE: PROOF OF PURCHASE, NAME, ADDRESS, AND PHONE NUMBER. YOUR PURCHASE PRICE AND ANY APPLICABLE TAXES WILL BE REFUNDED. PLEASE ALLOW 4-6 WEEKS TO PROCESS YOUR REFUND.

1. This License Agreement applies to the one or more databases that your product may contain. We refer to these singly as a "Database" and together as the "Databases." Your product may thus include the "WBS Database" which contains worldwide background surface mapping data, the "SmartMap Database" which contains inland mapping data, or other Databases.
2. The Databases that your product may contain are licensed, not sold. We grant to you the nonexclusive, nonassignable right to use these Databases for supplemental navigation reference purposes, but only as long as you comply with the terms and conditions of this License Agreement. We reserve the right to terminate this license if you violate any aspect of this License Agreement. You are responsible for using official government charts and prudent navigation for safe travel.
3. The Databases housed in your product are protected by the copyright notices appearing on the product or its screen(s). You may NOT modify, adapt, translate, reverse engineer, decompile, disassemble, rent, lease, or resell any Database, and you may NOT create derivative works based upon any Database or its contents.. Any unauthorized reproduction, use, or transfer of a Database may be a crime and may subject you to damages and attorney fees.
4. This License Agreement will terminate immediately without prior notice from us if you fail to comply with or violate any of the provisions of this Agreement. Upon termination, you will promptly return all products containing one or more Databases to us.
5. Prices and programs are subject to change without notice.
6. This License Agreement shall be governed by the laws of the State of Oklahoma and comprises the complete and exclusive understanding between you and us concerning the above subject matter.

LEI SOFTWARE LICENSE AGREEMENT AND ONE-YEAR MEDIA WARRANTY

NOTICE TO USER: THIS IS A CONTRACT. BY INSTALLING THIS SOFTWARE, YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT.

This LEI Extras* ("LEI") End User License Agreement accompanies the software contained on the CD-ROMs ("Software"). Upon your acceptance of this Agreement, LEI grants you a nonexclusive license to use the Software, provided that you agree to the following:

1) USE OF THE SOFTWARE

You may install and use the Software on a hard disk or other storage device. You may not use this software on more than one computer at the same time.

2) COPYRIGHT AND TRADEMARK RIGHTS

The Software is owned by LEI or its suppliers, and its structure, organization, and code are trade secrets. The Software is protected by United States copyright law and international treaty provisions.

3) RESTRICTIONS

You agree not to modify, adapt, translate, reverse engineer, decompile, disassemble, or otherwise attempt to discover the source code of the Software.

4) SOFTWARE WARRANTY

The Software is being delivered to you AS IS, and LEI makes no warranty as to its use or performance. **LEI MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AS TO THE MERCHANTABILITY OR FITNESS OF THE SOFTWARE FOR ANY PURPOSE. IN NO EVENT WILL LEI BE LIABLE TO YOU FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES.** Some states or jurisdictions do not allow the exclusion or limitation of consequential or incidental damages, so the above limitations may not apply to you.

5) MEDIA WARRANTY

LEI warrants that the media on which the Software is distributed is free from defects in materials and workmanship for one year from the date of the original purchase by you. Your remedies under this warranty will be available so long as you can show in a reasonable manner that any defect or malfunction in materials or workmanship occurred within one year from the date of your original purchase, which must be substantiated by a dated sales receipt or sales slip. Any such defect or malfunction which occurs within one year from your original purchase date will either be repaired without charge or be replaced with a new product identical or reasonably equivalent to this product, at our option, within a reasonable time after our receipt of the product. If such defect or malfunction remains after a reasonable number of attempts to repair by us, you may elect to obtain without charge a replacement of the product or a refund for the product. **THIS REPAIR, OR REPLACEMENT OR REFUND (AS JUST DESCRIBED) IS THE EXCLUSIVE REMEDY AVAILABLE TO YOU AGAINST US FOR ANY DEFECT OR MALFUNCTION CONCERNING THE PRODUCT'S MEDIA.** This media warranty does not apply in the following circumstances: (1) when any serial number has been effaced, altered or removed or (2) when any defect is caused by accident, misuse, improper storage or normal wear and tear.

6) GOVERNING LAW AND GENERAL PROVISIONS

This Agreement will be governed by the laws of the State of Oklahoma, USA. If any part of this Agreement is found void and unenforceable, it will not affect the validity of the remainder of the Agreement. This agreement shall automatically terminate upon failure by you to comply with its terms.

* LEI Extras is a division of Lowrance Electronics, Inc.

LEI EXTRAS, INC.

PO BOX 129

CATOOSA, OK 74015

Notes:



Pub. 988-0154-001

Printed in USA 021204

© Copyright 2004
All Rights Reserved
LEI Extras, Inc.